

# DIY SOY CANDLES

## SUPPLIES:

Provided in kit:

- 4 oz. yogurt jar
- Soy Wax
- Candle Wick
- Wick Sticker
- Fragrance Oil

Not provided:

- Microwave
- Microwavable dish (preferably something with a spout like a measuring cup)
- pencil, skewer, etc. to hold wick up



## INSTRUCTIONS:

1. Attach the bottom of the wick to the wick sticker, then affix the wick sticker to the inside base of the jar.
2. Wrap the wick that's above the jar top around a pencil or skewer to keep it straight.
3. Pour Soy Wax flakes into a microwavable dish – preferably something with a pouring spout.
4. Microwave wax for 1 minute, stir, then microwave for 30-second increments (stirring in between each time), until the wax has completely melted.
5. After the wax has melted, add in the fragrance oil.
6. Stir well, then carefully pour into your jar you prepared with wicks.
7. Allow the wax to solidify overnight, prop the top of the wick upright, trim the wick, and you're done!



**CHECK OUT OUR VIDEO  
TUTORIAL ON THE STAYTON  
PUBLIC LIBRARY YOUTUBE  
CHANNEL!**

**Share your completed project  
with us!**

- Text your photo to  
503-877-9893
- Email us at  
staytonpl@crls.org